


## RBD

Крышка угла 90°



### S F E


RBD 10S	100	0,2
RBD 20S	200	0,4
RBD 30S	300	1,0
RBD 40S	400	1,6
RBD 50S	500	2,9
RBD 60S	600	4,0

RBD 10F	100	0,2
RBD 20F	200	0,4
RBD 30F	300	1,0
RBD 40F	400	1,7
RBD 50F	500	3,1
RBD 60F	600	4,2

RBD 10E	100	0,2
RBD 20E	200	0,4
RBD 30E	300	1,0
RBD 40E	400	1,6
RBD 50E	500	2,9
RBD 60E	600	4,0

## RBDR

Крышка угла 90° с запорами



### S F E

RBDR 10S	100	0,2
RBDR 20S	200	0,4
RBDR 30S	300	1,0
RBDR 40S	400	1,6
RBDR 50S	500	2,8
RBDR 60S	600	3,9

RBDR 10F	100	0,2
RBDR 20F	200	0,5
RBDR 30F	300	1,1
RBDR 40F	400	1,7
RBDR 50F	500	3,1
RBDR 60F	600	4,2

RBDR 10E	100	0,2
RBDR 20E	200	0,5
RBDR 30E	300	1,0
RBDR 40E	400	1,6
RBDR 50E	500	2,7
RBDR 60E	600	3,7